

PT. DIKARI TATA UDARA INDONESIA SERVICE REPORT PM

Sales, Design, Service, Installation, Prepentive Maintenance AIR COOLED WATER CHILLER

Condensor ref. press.

Customer/User: DKR Location of Eq.: LT3

18 | Clean panel control box & Component

Engineer Name List :asd

FORM NO. COO-PM-11-24-00003

Stop Time: 11:11

Site: Ciomas

Code/No. of Eq. : asd

Start Time: 11:11

Date :2024-11-09

Tipe Form PM02

	TASKLIST Scope Of Work Maintenance	Freq.	Standard	Actual Check						
INITE	Chiller Elektrik ENSIVE SAFETY ? OK ? NOT OK			Check						
BRIEFING TEAM										
1	Check the evaporator refrigerant pressure and the condenser refrigerant.	Wkly	1	1						
2	Check the liquid line sight glasses.	Wkly	1	1						
3	Measure and record the system superheat.	1 M	3	3						
4	Measure and record the system subcooling.	1 M	3	3						
5	Manually rotate condenser fans to insure proper clearance.	1 M	3	3						
6	Check the fan assemblies for proper clearance in the fan openings	6 M	3	3						
7	Check motor shaft misalignment, abnormal end-play, vibration and noise.	6 M	3	3						
8	Check the oil level and refrigerant charge.	6 M	3	3						
9	Check oil analysis to determine system moisture content and acid level.	6 M	3	3						
10	Leak test the chiller	6 M	3	3						
11	Check operating and safety controls	6 M	3	3						
12	Inspect electrical components for deficiencies.	6 M	3	3						
13	Inspect all piping components for leakage and damage.	6 M	3	3						
14	Clean out any inline strainers.	6 M	3	3						
15	Clean and repaint any areas that show signs of corrosion.	6 M	3	3						
16	Clean the condenser coils.	6 M	3	3						
17	Clean the condenser fans.	6 M	3	3						

6 M

	SERVICE CHE	CK	
Unit Serial Number	:3	Elevation (°)	:3
Unit Model No.	:3	Nameplate Voltage (V)	:3
Compressor A Serial No.	:3	Fan Motor RLA	:3
Compressor A Model No.	:3	Evap Water Drop Press	s. (Bar)
Compressor B Serial No.	:3	Des. PSID :3	Act. PSID:3
Compressor B Model No.	:3	Des. GPM : 3	Act. GPM :3

Circuit Compressor	UoM	Standard	Be	fore	Af	ter	Remarks	
			Cir A	Cir B	Cir A	Cir B		
	R-S	Volt	3	3	3	3	3	
Unit Voltage	S-T	Volt	3	3	3	3	3	
	T-R	Volt	3	3	3	3	3	
	R	Amp	3	3	3	3	3	
Comp. Amp	S	Amp	3	3	3	3	3	
	Т	Amp	3	3	3	3	3	
Unit Operating Mode		3	3	3	3	3	3	
Last Diagnostic		3	3	3	3	3	3	
Evap EWT		3	3	3	3	3	3	
Evap LWT		3	3	3	3	3	3	
Outdoor Air Temp.		5	5	5	5	5	5	
Chilled Water Setpoint		5	5	5	5	5	5	
Current Limit Setpoint		5	5	5	5	5	5	
Sat. Evap. Ref. Temp.		5	5	5	5	5	5	
Sat. Cond. Ref. Temp.		7	7	7	7	7	7	

8

19	Check all sensor (Condition & read)	6 M	3	3	Evaporator ref. Press.		9	9	9	9	9	9
20	Check Cooler & Pi	pe Insulation	6 M	3	3	Compressor RLA		9	9	9	9	9	9
21	Check Condensor	air velocity	6 M	3	3	Compressor start		9	9	9	9	9	9
	FIND DH	NOTES / RECOMMENDATIONS			IS	Compressor hours		9	9	9	9	9	9
		*) Data gambar saat PM diinfokan melalui media lainnya.			Compressor hours		9	9	9	9	9	9	
						Oil Level Compressor		9	9	9	9	9	9
		APPROVAL								•			

CREATED BY

APPROVAL STATUS

Created By : adminsuper Completed Date : 12-12-12 Status Approval : Waiting Approved By : spv Approved Date : 12-12-12

	Foto Equipment		
No	Gambar	Info	Keterangan
1		9	Before
	Foto Parameter		
No	Gambar	Info	Keterangan
		9	Before