SERVICE REPORT PREVENTIVE MAINTENANCE PRECISION AIR CONDITIONING (PAC) PT. HM SAMPOERNA SUKOREJO PLANT

FORM NO.

Tipe Form

								PM04
₋okasi :	Model Unit :			Team Engineer List :			Date :	
Code unit :	No. Seri :]			Start PM:	
Nomor Unit :	Periode :						Close PM :	
CHECKLIST TEAM BRIE	FING							
NTENSIVE SAFETY BRIEF				?	OK	?	NOT OK	
ГЕАМ		Ī						
A Filter Section	Cross Borres /					Cmaa		
Item Checked	Spec. Range / Cond. Std.	Actual Checked				Range	Actual Checked	
1. Check/Replace filters	Clean or Dirty			5. Clean condensate pan		Clean or Dirty		
2. Grille area unrestricted	OK / Not OK			6. Clean trap in condensate drain		Clean or Dirty		
3. Wipe section clean	Clean or Dirty			7. Check/Test filter-		Ok or No		
4. Coil clean	Clean or Dirty			clog switch operation				
B Blower Section								
Item Checked	Spec. Range /		wer 1		wer 2		wer 3	Keterangan
4. Manustin or brake timb	Cond. Std.	Before	After	Before	After	Before	After	3
1. Mounting bolts tigh	t Ok or No Ok or No							
2. Fan-guard bolts tight								
3. Impeller spins freely	Ok or No							
4. Check/Test air sail switch	Ok or No							
5. Motor amp draw	FLA L1 = A	L1	L1	L1	L1	L1	L1	
Compare to	FLA L2 = A	L2	L2	L2	L2	L2	L2	
nameplate amps	FLA L3 = A	L3	L3	L3	L3	L3	L3	
6. Check belt tension and condition	Ok or No							
7. Check sheave/pulle	v Ok or No							
C Reheat	y en er ne							
	Spec. Range /	Hea	ter 1	Heater 2		Heater 3		I/ of our
Item Checked	Cond. Std.	Before	After	Before	After	Before	After	Keterangan
1. Reheat amp draw	FLA = A							
2. Check Heater Resistance	18-22 ohm							
3. Inspect elements	Ok or No							
4. Check wire connections	Ok or No							
D Steam Generating H	umidifier							
Item Checked	Spec. Range	Actual Checked		Item Checked			Spec. Range	Actual Checked
1. Humidifier amp drav	Humidifier amp draw A		4. Check condition of steam hose			Ok or No		
2. Check drain valve/drain lines/trap for damage/clogs/leaks	Ok or No			5. Clean strainer			Ok or No	
3. Check water fill valve and all supply lines/connection for leaks	Ok or No			6. Check humidifier bottle (Boiler tank)			Ok or No	
iean5				7. Check humidifie	operation o	of	Ok or No	