nage not found or type unl	PT. DIKARI TATA UDARA INDONESIA SERVICE REPORT PN
	Sales, Design, Service, Installation, Prepentive Maintenance AIR COOLED WATER CHILLER

		, , , , , , , , , , , , , , , , , , ,	<u> </u>	• `	
Customer/User : DKR	Location of Eq. :LT3	Engineer Name List :	Date :		FORM NO.
Site : Ciomas	Code/No. of Eq. : 12		Start Time	Stop Time	
	<u>'</u>				Tipe Form PM02

	TASKLIST			
	Scope Of Work Maintenance Chiller Elektrik	Freq.	Standard	Actual Check
	NSIVE SAFETY ? OK ? NOT OK FING TEAM			
1	Check the evaporator refrigerant pressure and the condenser refrigerant.	Wkly	1	1
2	Check the liquid line sight glasses.	Wkly	1	1
3	Measure and record the system superheat.	1 M	1	1
4	Measure and record the system subcooling.	1 M	1	1
5	Manually rotate condenser fans to insure proper clearance.	1 M	1	1
6	Check the fan assemblies for proper clearance in the fan openings	6 M	1	1
7	Check motor shaft misalignment, abnormal end- play, vibration and noise.	6 M	1	1
8	Check the oil level and refrigerant charge.	6 M	1	1
9	Check oil analysis to determine system moisture content and acid level.	6 M	1	1
10	Leak test the chiller	6 M	1	1
11	Check operating and safety controls	6 M	1	1
12	Inspect electrical components for deficiencies.	6 M	1	1
13	Inspect all piping components for leakage and damage.	6 M	1	1
14	Clean out any inline strainers.	6 M	1	1
15	Clean and repaint any areas that show signs of corrosion.	6 M	1	1
16	Clean the condenser coils.	6 M	1	1
17	Clean the condenser fans.	6 M	1	1
18	Clean panel control box & Component	6 M	1	1
19	Check all sensor (Condition & read)	6 M	1	1

ı			SERVIC	CE CHECK		
	Unit Serial Number	:1		Elevation (°)	:1	
İ	Unit Model No.	:1		Nameplate Voltage (V)	:1	
i	Compressor A Serial No.	:1		Fan Motor RLA	:1	
	Compressor A Model No.	:1		Evap Water Drop Press.	(Bar)	
ı	Compressor B Serial No.	:1		Des. PSID :1		Act. PSID:1
	Compressor B Model No.	:1		Des. GPM : 1		Act. GPM :1

Circuit Compressor		UoM	Standard		Ве	efore		After				Remarks	
			J. G.	Cir A Cir B		3	Cir A Cir B		110110				
	R	-S	Volt	35	3	6	3	7	3	8	:	39	40
Unit Voltage		S-T	Volt	35	3	6	3	7 38		3		39	40
	T-R	Volt	35	;	36	37		3	8	39)		40
	R	Amp	41	4	42	4:	3	4	4	45	5		46
Comp. Amp	S	Amp	41	4	42	43		4	4	45	5	46	
	Т	Amp	41	42		4:	43		4 45		5		46
Unit Operating I	Mode												
Last Diagnostic													
Evap EWT													
Evap LWT													
Outdoor Air Ter	np.												
Chilled Water S	etpoint												
Current Limit Se	Current Limit Setpoint												
Sat. Evap. Ref.	Sat. Evap. Ref. Temp.												,
Sat. Cond. Ref.	Temp.												
Condensor ref. press.												,	
Evaporator ref. Press.													

20	Check Cooler & Pipe Ir	nsulation	6 M	1 1	1	Compressor RLA							
21	Check Condensor air v	relocity	6 M	1	1	Compressor start							
	FIND DH	NOTES / REC	S	Compressor hours						'			
) Data qarribar saat Pivi qiiniokan melalul media lainnya.				Compressor hours								
				Oil Level Compressor									
			RESUME		APPRO	VAL SIGNING							
									Approved by		Verified I	-	Service By
			JOB COMPLETEI	LETED	ISS,			Supervisor,		Team Leader/Staf,			
						? YES							
			,			? NO, please on	check	No.	(<u>)</u> HP.	No. HP.	(_)		()
Kete	Keterangan : Lembar 1 untuk Teknisi; Lembar 2 untuk User; Lembar 3 Arsip Kantor					NOTES							No. HP.