PT. DIKARI TATA UDARA INDONESIA ENGINEERING DIVISION

SERVICE REPORT PM COLD STORAGE & CHAMBER

Sales, Design, Service, Installation, Prepentive Maintenance

Customer/User : DKR Engineer Name Lis

Site : Ciomas

Location of Eq. : LT3

Code/No. of Eq. : 1

Compressor Model No. : Evaporator Model No. : Fan Cond. Model No. :

Tipe Form PM05

SERVICE CHECK

Start Time : Stop Time :

	TASKLIST		1	
	Scope Of Work Maintenance cs	Freq.	Standard Cond.	Actual Check
INT	ENSIVE SAFETY BRIEFING TEAM ? OK ? NOT OK			
I	Compressor			
	Check Oil Condition (Pressure, Cleanliness & Level)	1	1	1
	2. Check HLPS Function	1	1	1
	3. Check gauge conditon (Press. & Temp. gauge)	1	1	1
	4. Check belt condition	1	1	1
	5. Check Compressor pressure (suction & discharge)	1	1	1
	Check suction & discharge temperature	1	1	1
	7. Check terminal block condition	1	1	1
	8. Check vibration & noise	1	1	1
	9. Check current compressor	1	1	1
	10. Check filter dryer condition	1	1	1
	11. Clean body compressor	1	1	1
	12. Check oil leak	1	1	1
	13. Check crankcase oil heater function	1	1	1
	14. Check solenoid valve function	1	1	1
	15. Clean oil strainer	1	1	1
	16. Replace oil compressor	1	1	1
	17. Replace core / filter dryer	1	1	1
	18. Check condensor fin condition (corosion & damage)	1	1	1
	19. Check pipe leakage	1	1	1
	20. Clean condensor coil & Body	1	1	1
	21. Clean panel control	1	1	1
II	Fans			
	1. Check vibration & Noise	1	1	1
	2. Check blade imbalance	1	1	1
	3. Check part corosion	1	1	1
	4. Clean blade & body	1	1	1
	5. Check current fans	1	1	1
	6. Replace bearing	1	1	1
III	Evaporator & Cooling Room			

. u v	ap. Model No :					
_	erant type :					
No	Description	Standard	Before	After		
1	Room Temp.		1	1	1	
2	Suction Press.	1	1	1		
3	Discharge Press.	1	1	1		
4	Suction Temp.	1	1	1		
5	Discharge Temp.	1	1	1		
	! ⊢	R-S	380	1	1	
6		S-T	380	1	1	
		T-R	380	1	1	
		R	1	11	1	
7	Comp 1 Amp S	S	1	1	1	
	Т		1	1	1	
	l	R	1	1	1	
8		S	1	1	1	
		Т	1	1	1	
	R		1	1	1	
9	Comp 3 Amp S	S	1	1	1	
		Т	1	1	1	
10	Oil Level	3/4	1	1		
11	1 Oil Cleanliness		Clean	Clean	Clean	
12	Ref. Sight glass		Clean			
13	Oil Pressure			Clean	Clean	
14	Crank. oil heater		OK/NOK	Ok	Ok	
15	Fan Cond 1 Amp		1	1	1	
16	Fan Cond 2 Amp			1 1		1
17	Fan condition			1	1	
18	Fan evap 1 Amp		1	1	1	
19	Fan evap 2 Amp		1	1	1	

Check fin condition (corosion & damage)	1	1	1	20	Fan evap 3 Amp	1	1	1		
2. Check pipe leakage	1	1	1	21	Fan evap 4 Amp	1	1	1		
3. Check TXV function	11	1	1	22	Fan evap 5 Amp	1	1	1		
4. Check defrost function	1	1	1	23	Fan evap 6 Amp	1	1	1		
5. Clean evaporator coil & Body	1	1	1	24	Fan Condition	1	1	1		
6. Check door heater function	1	1	1	25	Running Hours					
7. Check ventilation & infiltration	1	1	1] 23	Running nours			hours		
IV Tes running dan record data				RESUME						
FIND DH				Jo	JOB COMPLETED ?		? Yes ¥			
1										
		APPROVAL SIGNING								
		Approved by			Verified By		Service By			
		ISS,			Supervisor,	Te	Team Leader/Staf,			
NOTES / RECOMMENDATIONS										
11^st) Data gambar saat PM diinfokan melalui media lainnya.	(_)		()	()		
	No. HP			N	No. HP.	No. HP.				

Keterangan : Lembar 1 untuk Teknisi; Lembar 2 untuk User; Lembar 3 Arsip Kantor