mage not found ort/pe	ENGINEERING DIVISION	RA INDONESIA SERVICE REF Ve Maintenance AIR COOLED WATER			
Customer/User :	Location of Eq. :	Engineer Name List :	Date :	FORM NO.	
Site:	Code/No. of Eq. :		Start Time	Stop Time	
	· ·				Tipe Form

Unit Serial Number

Unit Model No.

TASKLIST								
	Scope Of Work Maintenance Chiller Elektrik	Freq.	Standard	Actual Check				
	ENSIVE SAFETY ? OK ? NOT OK EFING TEAM							
1	Check the evaporator refrigerant pressure and the condenser refrigerant.	Wkly	1	1				
2	Check the liquid line sight glasses.	Wkly	1	1				
3	Measure and record the system superheat.	1 M						
4	Measure and record the system subcooling.	1 M						
5	Manually rotate condenser fans to insure proper clearance.	1 M						
6	Check the fan assemblies for proper clearance in the fan openings	6 M						
7	Check motor shaft misalignment, abnormal end- play, vibration and noise.	6 M						
8	Check the oil level and refrigerant charge.	6 M						
9	Check oil analysis to determine system moisture content and acid level.	6 M						
10	Leak test the chiller	6 M						
11	Check operating and safety controls	6 M						
12	Inspect electrical components for deficiencies.	6 M						
13	Inspect all piping components for leakage and damage.	6 M						
	Clean out any inline strainers.	6 M						
	Clean and repaint any areas that show signs of corrosion.	6 M						
	Clean the condenser coils.	6 M						
	Clean the condenser fans.	6 M						
	Clean panel control box & Component	6 M						
	Check all sensor (Condition & read)	6 M						
20	Check Cooler & Pipe Insulation	6 M						
21	Check Condensor air velocity	6 M						
FIND DH NOTES / RECOMMENDATIONS								

Compressor A Serial No. :						Fan Motor RLA :				
Compressor A Model : No.						Evap Water Drop Press. (Bar)				
Compressor B Serial No. : Compressor B Model : No.					Des. PSID : Des. GPM :			Act. PSID: Act. GPM:		
Circuit Compressor		UoM	M Standard	Before			After		Remarks	
				Cir A	Cir	В	Cir A	Cir B		
	R-S	Volt								
Unit Voltage	S-T	Volt								
	T-R	Volt								
	R	Amp						,		
Comp. Amp	S	Amp						,		
	Т	Amp								
Unit Operating	Mode			,			1	,		
Last Diagnostic	;									
Evap EWT										
Evap LWT								,		
Outdoor Air Tei	mp.									
Chilled Water S							·			
Current Limit Setpoint										
Sat. Evap. Ref. Temp.				,				,		
Sat. Cond. Ref. Temp.										
Condensor ref. press.										
Evaporator ref. Press.										
Compressor RLA										
Compressor start			,							
Compressor hours										

SERVICE CHECK

Elevation (°)

Nameplate Voltage (V)

	*) Data gambar saat PM diinfokan melalui media lainnya.	Compressor hours			
		Oil Level Compressor			
		RESUME	APPROVAL SIGNING		
Ī			Approved by	Verified By	Service By
		JOB COMPLETED	ISS,	Supervisor,	Team
		?			Leader/Staf,
		? YES			
		? NO, please check	()	( )	
		on	No. HP.	No. HP.	( )
	Keterangan : Lembar 1 untuk Teknisi; Lembar 2 untuk User; Lembar 3 Arsip Kantor	NOTES			No. HP.