SERVICE REPORT PREVENTIVE MAINTENANCE

FORM NO.

		PRECISION A	IR CONDIT	IONING (F	PAC)				
			T. HM SAMP	•	•	.ANT			Tipe Form PM04
Lokasi :	Lokasi :				Team Engine	Team Engineer List :			
Code unit :		No. Seri :			1			Start PM:	
Nomor Unit :		Periode :						Close PM:	
CHECKLIST TEAM B	RIFFING								
INTENSIVE SAFETY BE						?	OK	?	NOT OK
A	Filter Section								
	Item Checked	Spec. Range / Cond. Std.	Actual Ch	ecked	Item Che	cked	Spec. Range	Actu	al Checked
	1. Check/Replace filters	Clean or Dirty			5. Clean con pan	densate	Clean or Dirty		
	2. Grille area unrestricted	OK / Not OK			6. Clean trap condensate	drain	Clean or Dirty		
	3. Wipe section clean	Clean or Dirty			7. Check/Tes		Ok or No		
	4. Coil clean	Clean or Dirty			switch opera	tion	OKOINO		
	В	Blower Section							
D - (Item Checked	Spec. Range /		1	Blower		Blower	r 3
Before 1. Mounting bolts tight		Ok or No	Cond. Std.	After	Before	After	Before	After	1
2. Fan-guard bolts	-	Ok or No		<u> </u>	1				
z. Fan-guard bons tight		OK OF NO							
3. Impeller spins freely		Ok or No							
4. Check/Test air sail switch		Ok or No							
5. Motor amp draw	1	FLA L1 = A	L1	L1	L1	L1	L1	L1	
Compare to		FLA L2 = A	L2	L2	L2	L2	L2	L2	
nameplate amps		FLA L3 = A	L3	L3	L3	L3	L3	L3	
6. Check belt tension and condition		Ok or No							
7. Check sheave/pulley	,	Ok or No						,	
C	Reheat	GR 61 116							
		Spec. Range /	Heater	1	Heater 2		Heater 3		Vataranara
	Item Checked	Cond. Std.	Before	After	Before After		Before	After	- Keterangan
	1. Reheat amp draw	FLA = A							
	2. Check Heater Resistance	18-22 ohm							
1	3 Inspect elements	Ok or No							

4. Check wire connections	Ok or No								
D	Steam Generating Humidifier								
	Item Checked	Spec. Range	Actua	I Checked	lí	em Checked		Spec. Range	Actual Checked
	1. Humidifier amp draw	A			Check condition of steam hose Clean strainer		ım hose	Ok or No	
	Check drain valve/drain lines/trap for damage/clogs/leaks	Ok or No						Ok or No	
	3. Check water fill valve and all supply lines/connection for	OkarNa		6. Check humidifier bottle (Boiler tank)		(Boiler	Ok or No		
	leaks	Ok or No			7. Check o	7. Check operation of humidifier		Ok or No	

E	Electrical Panel				
	Item Checked	Spec. Range /	Actual 0	Keterangan	
	item Checked	Cond. Std.	Before	After	Reterangan
	1. Check fuses	Ok or No			
	2. Check contactors for	Ok or No			
	pitting (Replace if pitted)	OK OF NO			
	3. Check/Re-torque wire				
	connections	Ok or No			

	Item Checked	Spec. Range		Keterangan			
	Cond. S		Before		After		
	4. Voltage Line to Neutral Ground	220 + 10%	L1/L2/L3 =	V	L1/L2/L3 =	V	
	5. Voltage Line to Line	380 + 10%	L1L2/L2L3/L1L3 =	V	L1L2/L2L3/L1L3 =	V	
	6. Frequency	50 + 10%	F =	Hz	F = Hz		
F	Controls						
	Item Checked	Spec. Range	Actual Checked Item Ch		tem Checked	Spec. Range	Actual Checked
		Cond. Std.				•	
	1. Check/Verify control operation	Ok or No		3. Check/ device	Test water-detection	Ok or No	
	2. Check/Test changeover device	Ok or No		4. Check/Test CAN connection between indoor and outdoor units		Ok or No	
G	Refrigeration Piping						
	Item Checked	Spec. Range	Actual Checked	ŀ	tem Checked	Spec. Range	Actual Checked

Check refrigerant lines (clamps secure/no rubbing/no leaks)	Ok or No			3. Check for restriction temperature drop across filter drier		Ok or No		
2. Check for moisture (sight glass)	Ok or No							
H Compressor Section								
Item Checked	Spec. Range	Com	np. 1	Con	Comp. 2 Com		np. 3	Keterangan
	Cond. Std.	Before	After	Before	After	Before	After	
1. Ampere draw	OA A							
2. Check oil level	55 - 90 PsiG							
3. Check for oil leaks	200 - 300 PsiG							
4. Check compressor mounts (springs/bushings)	Ok or No							
5. Cap tubes (not rubbing)	Ok or No							
6. Check/Re-torque wire connections (inside compressor box)	Ok or No							
7. Compressor operation (vibration/noise)	Hz dB							
8. Check crank-case heater fuses/operation	Ok or No							
9. Check for refrigerant leaks	Ok or No							
10. Suction pressure Circuit	55 - 90 PsiG							
11. Discharge Pressure Circuit	200 - 300 PsiG							
12. Superheat Circuit	?C							
13. Low-pressure switch cut out Circuit	Ok or No							
14. Low pressure cut in Circuit	Ok or No							
15. High pressure cut out Circuit	Ok or No							
16. Sight Glass	Ok or No							

I	Condensor Section						
	Item Check	red	Spec. Range	Before	At	iter	Keterangan
	Coil clean of debris (coil if required)	Clean	Clean or Dirty				
	2. Fans free of debris		Clean or Dirty				
	3. Fans securely mounted						
	4. Motor bearings in go						
	5. Check all refrigerant lines for vibration isolation. Support as necessary		Ok or No				
	6. Check for refrigerant		Ok or No				
	7. Check surge-protecti device (if installed) sta indicator lights	ion tus-	Ok or No				
	8. Check/Re-torque wire		Ok or No				
	9. Check contactors for (replace if pitted)	. •	Ok or No				
	10. Verify operation sec points						
	11. Charge verification:						
	a. Outdoor Ambient Ter	mperature					
	b. Subcooling						
	c. Indoor-unit Return-ai						
	d. Sight-glass level (if L Temp or pumped refriç	ee- gerant)					
	12. Motor amp draw		FLA = A	L1/L2/L3 = Amp	L1/L2/L3 = Amp		
J	General Function						
	Item Checked	Spec. Range	Actual Checked	Item Check		Spec. Range	Actual Checked
	1. Cooling Test	Ok or No		4. Dehumidification	Test	Ok or No	
	2. Heating Test	Ok or No		5. Alarm Test		Ok or No	
	3. Humidification Test	Ok or No					
K	Room Condition						
	Item Checked	Spec. Range	Actual Checked	Item Check	ed	Spec. Range	Actual Checked
	1. Temperature	?C		2. Humidity		%	
			NOT	ES			
Ten	nuan :						

Rekomendasi :		
	250.05	
	RESUME	
JOB COMPLETED ??YES	? NO, please check on NOTES	RUNNING HOURS :
	APPROVAL SIGNING	
Approved by	Verified By	Service By
ISS,	Supervisor,	Team Leader/Staf,
()	()	()
No. HP.	No. HP.	No. HP.

Keterangan : Lembar 1 untuk Teknisi; Lembar 2 untuk User; Lembar 3 Arsip Kantor