PT. DIKARI TATA UDARA INDONESIA ENGINEERING DIVISION

TASKLIST

....

SERVICE REPORT PM COLD STORAGE & CHAMBER

Sales, Design, Service, Installation, Prepentive Maintenance

Customer/User: DKR

Engineer Name

Site : Ciomas

Location of Eq. : LT3

Code/No. of Eq. : 1

Engineer Name List : ss

Date: 2024-07-30

FORM NO.

Tipe Form PM05

Start Time : Stop Time :

Scope Of Work Maintenance Coldstorage	Freq.	Standard Cond.	Actual Check
INTENSIVE SAFETY BRIEFING TEAM ? OK ? NOT OK			
I Compressor			
1. Check Oil Condition (Pressure, Cleanliness & Level)	1	1	1
2. Check HLPS Function	1	1	1
3. Check gauge conditon (Press. & Temp. gauge)	1	1	1
4. Check belt condition	1	1	1
5. Check Compressor pressure (suction & discharge)	1	1	1
6. Check suction & discharge temperature	11	1	1
7. Check terminal block condition	1	1	1
8. Check vibration & noise	1	1	1
9. Check current compressor	1	1	1
10. Check filter dryer condition	1	1	1
11. Clean body compressor	1	1	1
12. Check oil leak	1	1	1
13. Check crankcase oil heater function	1	1	1
14. Check solenoid valve function	1	1	1
15. Clean oil strainer	1	1	1
16. Replace oil compressor	1	1	1
17. Replace core / filter dryer	1	1	1
18. Check condensor fin condition (corosion & damage)	1	1	1
19. Check pipe leakage	1	1	1
20. Clean condensor coil & Body	1	1	1
21. Clean panel control	1	1	1
II Fans			
1. Check vibration & Noise	1	1	1
2. Check blade imbalance	1	1	1
3. Check part corosion	1	1	1
4. Clean blade & body	1	1	1
5. Check current fans	1	1	1
6. Replace bearing	1	1	1
III Evaporator & Cooling Room			

Compressor Model No.	:
Evaporator Model No.	:
Fan Cond. Model No.	:
Fan Evap. Model No	:
Refrigerant type	

Refrigerant type :								
No	Description		Standard	Before	After			
1	Room Temp.		1	1	1			
2	Suction Press.		1	1	1			
3	Discharge Press.		1	1	1			
4	Suction Temp.		1	1	1			
5	Discharge Temp.		1	1	1			
6	Voltage	R-S	380	1	1			
		S-T	380	1	1			
		T-R	380	1	1			
		R	1	1	1			
7	Comp 1 Amp	S	1	1	1			
		Т	1	1	1			
8	Comp 2 Amp	R	1	1	1			
		S	1	1	1			
		Т	1	1	1			
		R	1	1	1			
9 (Comp 3 Amp	S	1	1	1			
		Т	1	1	1			
10	Oil Level		3/4	1	1			
11	Oil Cleanliness		Clean	1	1			
12	Ref. Sight glass		Clean					
13	Oil Pressure			1	1			
14	Crank. oil heater		OK/NOK	1	1			
15	Fan Cond 1 Amp		1	1	1			
16	Fan Cond 2 Amp		1	1	1			
17	Fan condition		1	1	1			
18	Fan evap 1 Amp		1	1	1			
19	Fan evap 2 Amp		1	1	1			

SERVICE CHECK

1. Check fin condition (corosion & damage)	1	1	1	20	Fan evap 3 Amp	1	1	1
2. Check pipe leakage	1	1	1	21	Fan evap 4 Amp	1	1	1
3. Check TXV function	1	1	1	22	Fan evap 5 Amp	1	1	1
Check defrost function	1	1	1	23	Fan evap 6 Amp	1	11	1
5. Clean evaporator coil & Body	1	1	1	24	Fan Condition	1	1	1
6. Check door heater function	1	1	1	25	Dunning House			
7. Check ventilation & infiltration	1	1	1] 23	Running Hours			hours
IV Tes running dan record data		RESU			RESUME			
FIND DH			-	JOB COMPLETED ?		? YES	? NO, please check on NOTES	ē ⊃TES
					APPROVAL SIGNING			
	Approved by ISS,			Verified By Supervisor,		Service By Team Leader/Staf,		
NOTES / RECOMMENDATIONS								
*) Data gambar saat PM diinfokan melalui media lainnya.								
	No. HP)	N	() No. HP.	(_ No. HP.)

Keterangan : Lembar 1 untuk Teknisi; Lembar 2 untuk User; Lembar 3 Arsip Kantor