PT. DIKARI TATA UDARA INDONESIA ENGINEERING DIVISION

SERVICE REPORT PM COLD STORAGE & CHAMBER

Sales, Design, Service, Installation, Prepentive Maintenance

Customer/User: DKR

Site :

Location of Eq.:

Code/No. of Eq.:

Significant Name List:

Date:

FORM NO.

Tipe Form PM05

Start Time:

Stop Time:

	TASKLIST								
	Scope Of Work Maintenance Coldstorage		Freq.	Standard Cond.	Actual Check				
INT	INTENSIVE SAFETY BRIEFING TEAM ? OK ? NOT OK								
I	Compressor								
	Check Oil Condition (Pressure, Cleanliness & Level)								
	2. Check HLPS Function								
	3. Check gauge conditon (Press. & Temp. gauge)								
	4. Check belt condition								
	5. Check Compressor pressure (suction & discharge)								
	6. Check suction & discharge temperature								
	7. Check terminal block condition								
	8. Check vibration & noise								
	9. Check current compressor								
	10. Check filter dryer condition								
'	11. Clean body compressor								
	12. Check oil leak								
	13. Check crankcase oil heater function								
	14. Check solenoid valve function								
	15. Clean oil strainer								
	16. Replace oil compressor								
	17. Replace core / filter dryer								
	18. Check condensor fin condition (corosion & damage)								
	19. Check pipe leakage								
	20. Clean condensor coil & Body								
	21. Clean panel control								
=	Fans								
	Check vibration & Noise								
	2. Check blade imbalance								
	3. Check part corosion								
	4. Clean blade & body								
	5. Check current fans				i l				
	6. Replace bearing								
III	Evaporator & Cooling Room								

SERVICE CHECK Compressor Model No. : Evaporator Model No. : Fan Cond. Model No. : Fan Evap. Model No : Refrigerant type :

Refrigerant type :							
No	Description		Standard	Before	After		
1	Room Temp.						
2	Suction Press.						
3	Discharge Press.						
4	Suction Temp.						
5	Discharge Temp.						
	Voltage	R-S	380				
7		S-T	380				
		T-R	380				
	Comp 1 Amp	R					
7		S					
		Т					
	Comp 2 Amp	R					
8		S					
		Т					
	Comp 3 Amp	R					
9		S					
		Т					
10	Oil Level		3/4				
11	Oil Cleanliness		Clean				
12	Ref. Sight glass		Clean				
13	Oil Pressure						
14	Crank. oil heater		OK/NOK				
15	Fan Cond 1 Amp						
16	Fan Cond 2 Amp						
17	Fan condition						
18	Fan evap 1 Amp						
19	Fan evap 2 Amp						

1. Check fin condition (corosion & damage)		20	Fan evap 3 Amp				
2. Check pipe leakage		21	Fan evap 4 Amp				
3. Check TXV function		22	Fan evap 5 Amp				
4. Check defrost function		23	Fan evap 6 Amp				
5. Clean evaporator coil & Body		24	Fan Condition				
6. Check door heater function		25	Running Hours	-			
7. Check ventilation & infiltration		23	Running Hours		hours		
IV Tes running dan record data		RESUME					
FIND DH	JOB COMPLETED ? ? YES ? NO, please check on NOTES						
	APPROVAL SIGNING						
	Approved by ISS,		Verified By Supervisor,	Service By Team Leader/Staf,			
NOTES / RECOMMENDATIONS							
*) Data gambar saat PM diinfokan melalui media lainnya.	() No. HP.	Ν	() No. HP.	(No. HP.)		

Keterangan : Lembar 1 untuk Teknisi; Lembar 2 untuk User; Lembar 3 Arsip Kantor