PT. DIKARI TATA UDARA INDONESIA ENGINEERING DIVISION

Sales, Design, Service, Installation, Prepentive Maintenance

Code/No. of Eq. : 1

SERVICE REPORT PM COLD STORAGE & CHAMBER

Customer/User : DKR	Engineer Name List : ss	Date : 2024-07-30		FORM NO.
Site : Ciomas				
Location of Eq. : LT3				Tipe Form PM05
Lescation of Eq. : E10		Start Time :	Stop Time :	•

	TASKLIST							
	Scope Of Work Maintenance Coldstorage	Freq.	Standard Cond.	Actual Check				
INT	ENSIVE SAFETY BRIEFING TEAM ? OK ? NOT OK							
ı	Compressor							
	Check Oil Condition (Pressure, Cleanliness & Level)	1	1	1				
	2. Check HLPS Function	1	1	1				
	3. Check gauge conditon (Press. & Temp. gauge)	1	1	1				
	4. Check belt condition	1	1	1				
	5. Check Compressor pressure (suction & discharge)	1	1	1				
	6. Check suction & discharge temperature	11	1	1				
	7. Check terminal block condition	1	1	1				
	8. Check vibration & noise	1	1	1				
	9. Check current compressor							
	10. Check filter dryer condition							
	11. Clean body compressor							
	12. Check oil leak							
	13. Check crankcase oil heater function							
	14. Check solenoid valve function							
	15. Clean oil strainer							
	16. Replace oil compressor							
	17. Replace core / filter dryer							
	18. Check condensor fin condition (corosion & damage)							
	19. Check pipe leakage							
	20. Clean condensor coil & Body							
	21. Clean panel control							
II	Fans							
	1. Check vibration & Noise							
	2. Check blade imbalance							
	3. Check part corosion							
	4. Clean blade & body							
	5. Check current fans							
	6. Replace bearing							
III	Evaporator & Cooling Room							

		SERVICE CHECK
Compressor Model No.	:	
Evaporator Model No.	:	
Fan Cond. Model No.	:	
Fan Evap. Model No	:	
Refrigerant type	:	

No	Description		Standard	Before	After	
1	Room Temp.		1	1	1	
2	Suction Press.		1	1	1	
3	Discharge Press.		1	1	1	
4	Suction Temp.		1	1	1	
5	Discharge Temp.		1	1	1	
	Voltage	R-S	380	1	1	
6		S-T	380			
		T-R	380			
	Comp 1 Amp	R				
7		S				
		Т				
	Comp 2 Amp	R				
8		S				
		Т				
	Comp 3 Amp	R				
9		S				
		Т				
10	Oil Level		3/4			
11	Oil Cleanliness		Clean			
12	Ref. Sight glass		Clean			
13	Oil Pressure					
14	Crank. oil heater		OK/NOK			
15	Fan Cond 1 Amp					
16	Fan Cond 2 Amp					
17	Fan condition					
18	Fan evap 1 Amp					
19	Fan evap 2 Amp					
			•——	•	•	

1. Check fin condition (corosion & damage)		20	Fan evap 3 Amp			
2. Check pipe leakage		21	Fan evap 4 Amp			
3. Check TXV function		22	Fan evap 5 Amp			
4. Check defrost function		23	Fan evap 6 Amp			
5. Clean evaporator coil & Body		24	Fan Condition			
6. Check door heater function		25	Dunning Hours			
7. Check ventilation & infiltration		23	Running Hours		hours	
IV Tes running dan record data		RESUME				
FIND DH	JOB COMPLETED ? ? YES ? NO, please check on NOTES					
	APPROVAL SIGNING					
	Approved by ISS,	Verified By Supervisor,		Service By Team Leader/Staf,		
NOTES / RECOMMENDATIONS						
*) Data gambar saat PM diinfokan melalui media lainnya.	() No. HP.	Ν	() No. HP.	(No. HP.)	

Keterangan : Lembar 1 untuk Teknisi; Lembar 2 untuk User; Lembar 3 Arsip Kantor