



PT. DIKARI TATA UDARA INDONESIA
ENGINEERING DIVISION
Sales, Design, Service, Installation, Prepentive Maintenance

SERVICE REPORT PM

AIR COOLED WATER CHILLER

Customer/User : DKR	Location of Eq. :LT3	Engineer Name List :	Date :	FORM NO.
Site : Ciomas	Code/No. of Eq. : 12		Start Time	Stop Time
				Tipe Form PM02

TASKLIST				
Scope Of Work Maintenance Chiller Elektrik		Freq.	Standard	Actual Check
INTENSIVE SAFETY BRIEFING ? OK ? NOT OK TEAM				
1	Check the evaporator refrigerant pressure and the condenser refrigerant .	Wkly	1	1
2	Check the liquid line sight glasses.	Wkly	1	1
3	Measure and record the system superheat.	1 M	1	1
4	Measure and record the system subcooling.	1 M	1	1
5	Manually rotate condenser fans to insure proper clearance.	1 M	1	1
6	Check the fan assemblies for proper clearance in the fan openings	6 M	1	1
7	Check motor shaft misalignment, abnormal end-play, vibration and noise.	6 M	1	1
8	Check the oil level and refrigerant charge.	6 M	1	1
9	Check oil analysis to determine system moisture content and acid level.	6 M	1	1
10	Leak test the chiller	6 M	1	1
11	Check operating and safety controls	6 M	1	1
12	Inspect electrical components for deficiencies.	6 M	1	1
13	Inspect all piping components for leakage and damage.	6 M	1	1
14	Clean out any inline strainers.	6 M	1	1
15	Clean and repaint any areas that show signs of corrosion.	6 M	1	1
16	Clean the condenser coils.	6 M	1	1
17	Clean the condenser fans.	6 M	1	1
18	Clean panel control box & Component	6 M	1	1
19	Check all sensor (Condition & read)	6 M	1	1
20	Check Cooler & Pipe Insulation	6 M	1	1

SERVICE CHECK											
Unit Serial Number : 1						Elevation (°) : 1					
Unit Model No. : 1						Nameplate Voltage (V) : 1					
Compressor A Serial No. : 1						Fan Motor RLA : 1					
Compressor A Model : 1						Evap Water Drop Press. (Bar)					
No.											
Compressor B Serial No. : 1											
Compressor B Model : 1						Des. PSID : 1			Act. PSID : 1		
No.						Des. GPM : 1			Act. GPM : 1		
Circuit Compressor		UoM	Standard	Before				After		Remarks	
				Cir A		Cir B		Cir A	Cir B		
Unit Voltage	R-S	Volt	1	1		1	1	1	1		
	S-T	Volt	1	1	1	1	1	1			
	T-R	Volt									
Comp. Amp	R	Amp									
	S	Amp									
	T	Amp									
Unit Operating Mode											
Last Diagnostic											
Evap EWT											
Evap LWT											
Outdoor Air Temp.											
Chilled Water Setpoint											
Current Limit Setpoint											
Sat. Evap. Ref. Temp.											
Sat. Cond. Ref. Temp.											
Condensor ref. press.											
Evaporator ref. Press.											
Compressor RLA											

21	Check Condensor air velocity	6 M	1	1	Compressor start							
FIND DH		NOTES / RECOMMENDATIONS			Compressor hours							
		*) Data gambar saat PM diinfokan melalui media lainnya.			Compressor hours							
					Oil Level							
					Compressor							
					RESUME		APPROVAL SIGNING					
					JOB COMPLETED ?		Approved by ISS,		Verified By Supervisor,		Service By Team Leader/Staf,	
? YES												
? NO, please check on		No. HP. ()		No. HP. ()		No. HP. ()						
NOTES												
Keterangan : Lembar 1 untuk Teknisi; Lembar 2 untuk User; Lembar 3 Arsip Kantor												