mage not found or t	ENGINEERING DIVISION	INDONESIA SERVICE REPO Maintenance AIR COOLED WATER			
ustomer/User :	Location of Eq. :	Engineer Name List :	Date :		FORM NO.
te:	Code/No. of Eq. :		Start Time	Stop Time	
					Tipe Form

TASKLIST									
	Scope Of Work Maintenance Chiller Elektrik	Freq.	Standard	Actual Check					
	INTENSIVE SAFETY ? OK ? NOT OK BRIEFING TEAM								
1	Check the evaporator refrigerant pressure and the condenser refrigerant.	Wkly	1	1					
2	Check the liquid line sight glasses.	Wkly	1	1					
3	Measure and record the system superheat.	1 M	1	1					
4	Measure and record the system subcooling.	1 M	1	1					
5	Manually rotate condenser fans to insure proper clearance.	1 M	1	1					
6	Check the fan assemblies for proper clearance in the fan openings	6 M	1	1					
7	Check motor shaft misalignment, abnormal end-play, vibration and noise.	6 M	1	1 R					
8	Check the oil level and refrigerant charge.	6 M							
9	Check oil analysis to determine system moisture content and acid level.	6 M							
10	Leak test the chiller	6 M							
11	Check operating and safety controls	6 M							
12	Inspect electrical components for deficiencies.	6 M							
13	Inspect all piping components for leakage and damage.								
14	Clean out any inline strainers.	6 M							
15	Clean and repaint any areas that show signs of corrosion.	6 M							
16	Clean the condenser coils.	6 M							
17	Clean the condenser fans.	6 M							
18	Clean panel control box & Component	6 M							
19	Check all sensor (Condition & read)	6 M							
20	Check Cooler & Pipe Insulation	6 M							
21	Check Condensor air velocity FIND DH NOTES / RECO	6 M							

Unit Serial Number		:				Elevation (°) :					
Unit Model No.	:				Nameplate Voltage (V) :						
Compressor A S	:				Fan Motor RLA :						
Compressor A N	Compressor A Model No.		:				Evap Water Drop Press. (Bar)				
Compressor B S Compressor B N						Des. F Des. C	-		Act. PSID: Act. GPM:		
Circuit Compressor		UoM Stan	Standard	Before			After		Remarks		
			Staridard	Cir A	Cir	r В	Cir A	Cir B	Nemarks		
	R-S	Volt					,				
Unit Voltage	S-T	Volt									
	T-R	Volt									
Amp											
Comp. Amp	S	Amp									
	Т	Amp									
Unit Operating N	/lode						,				
Last Diagnostic											
Evap EWT											
Evap LWT											
Outdoor Air Temp.							,				
Chilled Water Se											
Current Limit Setpoint							,				
Sat. Evap. Ref. Temp.											
Sat. Cond. Ref. Temp.											
Condensor ref. press.											
Evaporator ref. Press.											
Compressor RLA											
Compressor start											
Compressor hours								1			

SERVICE CHECK

¹) Data gambar saat PM diinfokan melalui media lainnya.	Compressor hours Oil Level Compressor			
	RESUME	APPROVAL SIGNING		
	JOB COMPLETED	Approved by ISS,	Verified By Supervisor,	Service By Team Leader/Staf,
	? YES			
Keterangan : Lembar 1 untuk Teknisi; Lembar 2 untuk User; Lembar 3 Arsip Kantor	? NO, please check on NOTES	() No. HP.	() No. HP.	() No. HP.