## SERVICE REPORT PREVENTIVE MAINTENANCE PRECISION AIR CONDITIONING (PAC) PT. HM SAMPOERNA SUKOREJO PLANT

					_				
Lokasi :		Model Unit:	Team Engineer List:			Date :			
Code unit :		No. Seri :			1			Start PM:	
Nomor Unit :		Periode :						Close PM:	
							1		Ξ
	CKLIST TEAM BRIEFING	•							
INIE	ENSIVE SAFETY BRIEFING TEAN	1					OK		N
Α	Filter Section								
	Item Checked	Spec. Range /	Actual Ch	aakad	Item Che	akad	Spec.	Actua	-L (
	item Checked	Cond. Std.	Actual Ch	<b>ескеа</b>	item Che	скеа	Range	Actua	<b>31 (</b>
	1 Chack/Bankas filters	Class or Dirty			5. Clean con	densate	Clean or		
	1. Check/Replace filters	Clean or Dirty			pan		Dirty		
	2. Grille area unrestricted	OK / Not OK			6. Clean trap		Clean or		
		OK/ NOLOK			condensate		Dirty		
	3. Wipe section clean	Clean or Dirty			7. Check/Tes		Ok or No		
	4. Coil clean	Clean or Dirty			switch opera	tion	OK OF 140		
В	Blower Section				_				
	Item Checked	Spec. Range /	Blower 1		Blower 2		Blower	3	
	Rem oncored	Cond. Std.	Before	After	Before	After	Before	After	
	1. Mounting bolts tight	Ok or No							
	2. Fan-guard bolts tight	Ok or No							
	3. Impeller spins freely	Ok or No							
	4. Check/Test air sail	Ok or No							
	switch	OK OF INO							
	5. Motor amp draw	FLA L1 = A	L1	L1	L1	L1	L1	L1	
	Compare to nameplate	FLA L2 = A	L2	L2	L2	L2	L2	L2	
	amps	FLA L3 = A	L3	L3	L3	L3	L3	L3	Г
	6. Check belt tension and	<u> </u>							Г
	condition	Ok or No							
	7. Check sheave/pulley	Ok or No							T
С	Reheat								
		Spec. Range /	c. Range / Heater 1		Heater 2		Heater 3		Г
	Item Checked	Cond. Std.	Before	After	Before	After	Before	After	
	1. Reheat amp draw	FLA = A							Г
	2. Check Heater								T
	Resistance	18-22 ohm							
	3. Inspect elements	Ok or No			1				H
									T
	4. Check wire connections	Ok or No							
D	Steam Generating Humidifier					Į.			
								Spec.	
	Item Checked	Spec. Range	Actual Checked		Iten	n Checked		Range	
	1. Humidifier amp draw	A			4. Check cor	ndition of stea	m hose	Ok or No	Г
	2. Check drain								
	valve/drain lines/trap for	Ok or No			5. Clean stra	iner		Ok or No	
	damage/clogs/leaks				1			L	L
	3. Check water fill valve and				6. Check humidifier bottle (Boi tank)		(Boiler	Ok or No	
all supply lines/connection for		Ok or No							L
	leaks	OK OF 140			7. Check one	eration of hum	idifier	Ok or No	
					Ti Gilook op c	ration or main		OK OF THE	
Ε	Electrical Panel								
	Item Checked	Spec. Range /	Before		Actual Checked				
		Cond. Std.					After		
	1. Check fuses	Ok or No				ļ			$\vdash$
	2. Check contactors for	Ok or No							
	pitting (Replace if pitted)					<del>                                     </del>			$\vdash$
	3. Check/Re-torque wire	Ok or No				1			
	connections	Ok or No	I			1			1