Sales, Design, Service, Installation, Prepentive Maintenance AIR COOLED WATER CHILLER							
Customer/User :	Location of Eq. :	Engineer Name List :	Date :		FORM NO.		
Site:	Code/No. of Eq. :		Start Time	Stop Time			
	'				Tipe Form PM02		

Unit Serial Number

Unit Model No.

TASKLIST								
	Scope Of Work Maintenance Chiller Elektrik	Freq.	Standard	Actual Check				
INTENSIVE SAFETY ? OK ? NOT OK BRIEFING TEAM								
1	Check the evaporator refrigerant pressure and the condenser refrigerant.	Wkly	1	1				
2	Check the liquid line sight glasses.	Wkly	1	1				
3	Measure and record the system superheat.	1 M	1	1				
4	Measure and record the system subcooling.	1 M						
5	Manually rotate condenser fans to insure proper clearance.	1 M						
6	Check the fan assemblies for proper clearance in the fan openings	6 M						
7	Check motor shaft misalignment, abnormal end- play, vibration and noise.	6 M						
8	Check the oil level and refrigerant charge.	6 M						
9	Check oil analysis to determine system moisture content and acid level.	6 M						
10	Leak test the chiller	6 M						
11	Check operating and safety controls	6 M						
12	Inspect electrical components for deficiencies.	6 M						
13	Inspect all piping components for leakage and damage.	6 M						
14	Clean out any inline strainers.	6 M						
15	Clean and repaint any areas that show signs of corrosion.	6 M						
16	Clean the condenser coils.	6 M						
17	Clean the condenser fans.	6 M						
18	Clean panel control box & Component	6 M						
19	Check all sensor (Condition & read)	6 M						
20	Check Cooler & Pipe Insulation	6 M						
21	Check Condensor air velocity FIND DH NOTES / RECO	6 M						

Compressor A Serial No. : Compressor A Model : No.						Fan Motor RLA :				
						Evap Water Drop Press. (Bar)				
Compressor B Serial No. : Compressor B Model : No.				Des. PSID : Des. GPM :			Act. PSID: Act. GPM:			
Circuit Compressor		UoM	Standard	Before			After		Remarks	
				Cir A	Cir	В	Cir A	Cir B		
	R-S	Volt								
Unit Voltage	S-T	Volt								
	T-R	Volt								
	R	Amp		,						
Comp. Amp	S	Amp								
	Т	Amp								
Unit Operating N	Лode			,			,			
Last Diagnostic				'						
Evap EWT										
	Evap LWT									
Outdoor Air Tem	Outdoor Air Temp.									
Chilled Water Setpoint							,			
Current Limit Setpoint							,			
Sat. Evap. Ref. Temp.							,			
Sat. Cond. Ref. Temp.										
Condensor ref. press.										
Evaporator ref. Press.										
Compressor RLA										
Compressor start										
Compressor hours										

SERVICE CHECK

Elevation (°)

Nameplate Voltage (V)

	*) Data gambar saat PM diinfokan melalui media lainnya.	Compressor hours			
		Oil Level Compressor			
		RESUME	APPROVAL SIGNING		
Ī			Approved by	Verified By	Service By
		JOB COMPLETED	ISS,	Supervisor,	Team
		?			Leader/Staf,
		? YES			
		? NO, please check	()	()	
		on	No. HP.	No. HP.	()
	Keterangan : Lembar 1 untuk Teknisi; Lembar 2 untuk User; Lembar 3 Arsip Kantor	NOTES			No. HP.